PROFESSIONAL CYCLING HEADLIGHT

USER MANUAL

Please unlock the device before use.
Quickly press the power button 5 times continuously until the green power indicator light is on.

RoHS CE FC

MADE IN CHINA

PRODUCT DESCRIP


Headlight


Handlebar Mount


GOPRO Mount Conversion


USB Cable

HOW TO INSTALL


① Unfold the strap of the bracket and tie it to the handlebar.


② Install the nut and tighten.


③ Put the base of the light into the holder, then rotate it 90°.


④ Adjust the light irradiation angle so that the light will not shine on the opposite drivers and pedestrians, tighten the nut, and the installation is complete.

REVERSE HANGING INSTALL


①.Follow the unlock arrow indicator to turn the lens and then remove the lens.


②.Flip the lamp body, the lens low beam icon is 45 degrees upward to enter the light. Turn the lens as the direction of the lock arrow,and reverse the orientation of the lens, then hang the light on the handlebar and finish the installation.

Note: ●Correct use of anti-glare function: Please keep the low beam icon of the lens directly above the lamp.
●It is forbidden to use the lamps after removing the lens. The lamps has no waterproof function after removing the lens.
●Please keep the lens and lamp bead surface clean, otherwise the service life will be affected.

LOCK MODE

To prevent potential damage from high heat or even fire,it is very important to put the bicycle light in lock mode and protect the switch brom being pressed.We will not be held responsible for damages to person or property resulting from a failure to follow the lock mode instructions.

Lock:
When power off, quickly press the power button 5 times until the power indicator flashes red.

Unlock:
When device lock, quickly press the power button 5 times continuously until the green power indicator light is on.

INSTRUCTIONS



Switch Machine Press and hold the switch for 0.5 seconds.
Mode memory function(when youn turn the lighton, it lights in the last lighting mode you used).

Switch Mode When the device is power-on, Click to switch the gear of the light, Double-click to switch between flashing mode or steady light mode.
Steady light mode has 4 gears: High, Medium, Low, ECO.
Flashing mode has 2 gears: Flashing Fast, Flashing Slow.

HOW TO RECHARGE


Charging:Red


Fully charged:Green

1.Open the USB waterproof plug and insert thecharging cable into the USB Type-C port.
2.Connect the other end of the charging line to the charging equipment.
Note: Please fully charge before the first use.
After charging is complete, please unplug the charging cable and make sure to cover the USB waterproof plug.

BATTERY INDICATOR

Color	Green	Blue	Red
Remaining Power	80%-100%	30%-80%	Below 30%

Power-On State: Flash on Power Button automatically every 3 seconds.
Power-Off State: Flash on Power Button after single click.